



Notes:

- Program radio accessory connector pin 3 for voice PTT active low.
- Enable accessory connector mic in miscellaneous-microphone.
- Select Rx Audio(Accessory Connector): Filtered Squelched in miscellaneous-global
- Enable Ignition Sense in miscellaneous-global

For Motorola CM w/o Virtual Control Head

Connection Cable	Drawn by NEB	Page no 1
Document Cable drawing	Rev A	Date 20-05-18
	Nr	
LS Elektronik AB	3021/02-05	