

Cable Kit 3293 Interface 3130 or 3009/09

Mimer SoftRadio for Icom A25

Remote functionality

This cable kit will together with the Mimer Network Interface give remote control of the portable's audio and PTT functions.

Radio programming

See next page for recommended settings.

Connection

The red and black wires shall be connected to 12VDC, red is positive.

The network interface consumes max 0,3A.



Icom airband radio with network interface LE

Recommended Settings

Audio level

The audio output from radio to interface is dependent of the volume control on the radio. The interface is tuned at delivery for the volume control to be in the “half-volume” position.

Menu functions

The radio also has a few functions that it is better to turn off when used with SoftRadio.

Vox controlled PTT

The vox function will trigger PTT on the radio as soon as there is audio on the microphone. This is not preferred when remote controlling.

Turn off!

◇ VOX Set

(([MENU] > Radio Settings > VOX Set)

Turn the VOX function ON or OFF.

The function automatically switches between receive and transmit by detecting your voice.

- OFF: Turns OFF the function.
- ON: Switches between receive and transmit by detecting your voice.

Side tone

This function gives the radio user his own voice in the speaker. Practical when using a headset. Not preferred in any other setup.

Turn off!

◇ Side Tone

(([MENU] > Sounds Settings > Side Tone)

Set the side tone output level to between 1 (lowest) and 10 (highest), or OFF.

The Side tone function outputs the transmitting audio to the headset connected to the transceiver.

NOTE:

When using the optional HM-231 HAND MICROPHONE, set the side tone output level to OFF. Otherwise, your voice will be heard from the speaker while transmitting.